



To create a new software CD/DVD for your product, please download the XXXXX-Software_Disk.exe where XXXXX is the project number of your unit. The project number can be found on the unit itself or on the original box the product came in. The project number is in the following format: PXXXXX.

PLEASE NOTE: This process requires a CD / DVD Burner.


When you have saved the file to your computer, please insert a CD/DVD into your CD/DVD burner and double click the file.





Click Ja (Yes)




Now the CD/DVD is extracted and made ready to be burned to disk



If the above image is shown, click Nej (No)




Now the CD/DVD is burned



If the above is shown, please close the CD/DVD burner to start the verification process.

Now the CD/DVD is checked



When the verification process is done the new CD/DVD is ready for use with your product.